

MicroSpray Photoresist

Description


MicroSpray is a positive acting, aerosol resist, well suited for a broad range of lithographic purposes. This cost effective, easy to use, spray can eliminates many of the process problems associated with spin coating thick resists and non-planar substrates such as those found in MEMS, opto-electronics and other non-standard applications.

Applications

- Conformal coatings
- Ideal for perforated, small, large & irregular shaped substrates
- Backside wafer coatings
- Severe topography, v-grooves, vias & other MEMS structures
- Microfluidic electrophoresis analysis (Lab-on-a-chip)

Product Attributes

- Multipurpose resist product–excellent R&D tool
- No expensive coating equipment required
- Thick resist coatings demonstrated from 6–16 μm
- Compatible with MIF and metal-ion aqueous developers
- High throughput for thick films



4 μm Lines/Spaces in 16 μm Thick Spray Coating of MicroSpray

MicroSpray Product Specifications

Container: Aerosol can

Weight: 16 ounces (454 grams)

Dimensions: 8 inches tall, 2.5 inches diameter

Resist volume: 14.5 ounces (411 grams)

Coatings: 200, 4 inch wafers

(approximate)

Shipping: Air or ground

Table 1. Process Parameters






How to Use MicroSpray

- Store can refrigerated for best use
- Place can at room temperature 1 hour prior to use
- Shake can vigorously 10 times
- Wait 5 minutes
- Make sure substrate is clean
- Prime wafer with HMDS
- Spray distance 3 inches
- Spray surface with 6 passes and change direction of spray after 3 passes to form an overlapping pattern
- Wait 5 minutes (micro-bubbles will disappear)
- Bake coated substrate for 3 minutes at 110°C
- Expose coated substrate to UV light (350-450 mJ/cm²)
- Develop for 4-6 minutes in 2.38% TMAH (or NaOH)
- Rinse and dry

Coating Uniformity



Coating thickness (100 mm)
Standard deviation

9.14 μm 0.24 μm

Handling

MicroSpray is an exremely flammable aerosol. Keep from open flames, electrostatic discharges and other sources of ignition. Avoid contact with eyes, skin and clothing. Use with adequate ventilation and avoid breathing chemical spray. Wear chemical-resistant eye protection, chemical-resistant gloves and protective clothing when handling MicroSpray. Exposure from MicroSpray products may cause drowsiness or dizziness, skin irritation, allergic skin reactions and/or serious eye irritation. If inhaled, supply fresh air and

contact physician if symptoms of exposure persist. In the case of exposure to skin, immediately wash with water and soap and rinse thoroughly. If there is an exposure to the eyes, rinse cautiously with water for at least 20 minutes. remove contact lenses, if present and easy to do. Review all sections of the Safety Data Sheet before using.

Consult Safety Data Sheet (SDS) for details on the handling procedures and product hazards prior to use. If you have any questions regarding handling precautions or product hazards, please email productsafety@kayakuAM.com.

Material and Equipment

MicroSpray is compatible with glass, ceramic, unfilled polypropylene, high-density polyethylene, polytetra-fluoroethylene, stainless steel and equivalent materials. MicroSpray products are compatible with most commercial resist processing equipment.

Storage

Store upright in original sealed containers in a dry area between 10°C and 21°C (50-70°F). Keep away from sources of ignition, light, heat, oxidants, acids and reducers. Do not use product after the expiration date (13 months from date of manufacture).

Disposal

The material and its container must be disposed in accordance with all local, state, federal and/or international regulations.

Disclaimer

Notwithstanding anything to the contrary contained in any sales documentation, e.g., purchase order forms, all sales are made on the following conditions:

All information contained in any Kayaku Advanced Materials product literature reflects our current knowledge on the subject and is, we believe, reliable. It is offered solely to provide possible suggestions for the customer's own experiments and is not a substitute for any testing by the customer to

MicroSpray Technical Data Sheet, Ver. 1, August 2020, Page 2/3





determine the suitability of any of Kayaku Advanced Materials products for any particular purpose. This information may be subject to revision as new knowledge and experience becomes available, but Kayaku Advanced Materials assumes no obligation to update or revise any data previously furnished to a customer; and if currency of data becomes an issue, the customer should contact Kayaku Advanced Materials requesting updates. Since Kayaku Advanced Materials cannot anticipate all variations in actual end uses or in actual end-use conditions, it makes no claims, representations or warranties, express or implied including, without limitation any warranty of merchantability or fitness for a particular purpose; and the customer waives all of the same. Kayaku Advanced Materials expressly disclaims any responsibility or liability and assumes no responsibility or liability in connection with any use of this information including, without limitation, any use, handling, storage or possession of any Kayaku Advanced Materials products, or the application of any process described herein or the results desired or anything relating to the design of the customer's products. Nothing in this publication is to be considered as a license to operate under or a recommendation to infringe any patent right.

MicroSpray Technical Data Sheet, Ver. 1, August 2020, Page 3/3

